

# IMPORTANT Installation Instructions:

**JUST 2 SIMPLE STEPS TO INSTALL**

## Install **WAX FREE Toilet Seal** on **CLEAN Toilet Horn FIRST!**

**NOTE:** If installing on an existing toilet, remove ALL old wax and residue with a household cleaner and DRY COMPLETELY.



**1)** Remove paper seal from adhesive and firmly press the Fernco WAX FREE Toilet Seal over the horn on the bottom of the toilet.

**2)** Align the Fernco WAX FREE Toilet Seal with the floor drain and the flange bolts and lower into desired position. *To ease installation, lubricate the flexible ribs with soapy water.*



Toilet can be repositioned as needed unlike with messy wax rings.