

# RECOMMENDED ACCESSORIES FOR AIR CONDITIONING

Model	A/C Capability Up To:	A/C Blower 3.5 Ton	A/C Blower 4 Ton	Relay Box 2 Wire	Relay Box 5 Wire	Adapter Brkt.- Relay Box
M(G,M) HA-01-2						
56	2	901998/902809	901998/902810	901994	901995	N/A
70	21/2	901998/902809	901998/902810	901994	901995	N/A
77	3	901998/902809	901998/902810	901994	901995	N/A
90	3	901998/902809	901998/902810	901994	901995	N/A
M(G,M) HB-01						
56	3	901998/902809	901998/902810	N/A	N/A	N/A
70	3	901998/902809	901998/902810	N/A	N/A	N/A
77	3	901998/902809	901998/902810	N/A	N/A	N/A
90	4	901998/902809	901998/902810	N/A	N/A	N/A
M(B,S) HA-01						
66	21/2	901998/902809	901998/902810	901994	901995	N/A
86	3	901998/902809	901998/902810	901994	901995	N/A
M(G,M) BA-01	4	N/A	N/A	901994	901995	N/A
M(B,S) BA-01	4	N/A	N/A	901994	901995	N/A
M(G,M) BB-01	4	N/A	N/A	N/A	N/A	N/A
M(B,S) HA-05,07						
66	21/2	902809	902810	901994	901995	901908
86	3	902809	902810	901994	901995	901908
M(G,M) HA-05						
56	2	902809	902810	90289	902898	N/A
70	21/2	902809	902810	902897	902898	N/A
77	3	902809	902810	902897	902898	N/A
90	3	902809	902810	902897	902898	N/A
M(G,M) HB-06						
56	3	902809	902810	N/A	N/A	N/A
70	3	902809	902810	N/A	N/A	N/A
77	3	902809	902810	N/A	N/A	N/A
90	3	902809	902810	N/A	N/A	N/A
M(G,M) BB-06						
56	4	N/A	N/A	N/A	N/A	N/A
70	4	N/A	N/A	N/A	N/A	N/A
77	4	N/A	N/A	N/A	N/A	N/A
90	4	N/A	N/A	N/A	N/A	N/A
M(B,S) BA-05,07						
66	4	N/A	N/A	901994	901995	902908
86	4	N/A	N/A	901994	901995	902908

1. -06 Models, A/C Ready
2. -05 Models, needs new relay boxes and blowers.
3. -01 and -02 Models with new blower assemblies and old style relay box need adapter bracket.

# RECOMMENDED ACCESSORIES FOR AIR CONDITIONING

MAC series, MGH, MSH, RSH, MBH, RBH: type 1 series only	901650-2 wire 901650-5 wire	<i>Adapt Plug</i> 901344	<i>Bracket</i> 901660	<i>Transformer</i> 910910
MGH, MSH, MBH type 2 series thru production 1990	901650-2 wire 901030-5 wire	none	none	910910
MGHA/MMHA MSHA/MBHA	901998-blower+ 901994-2 wire or 901995-5 wire	none	none	none
MGHB/MMHB MGBB/MMBB	AC ready thru 3 ton, with existing blower, relay and transformer. AC ready thru 4 ton, with existing blower, relay and transformer.			

7600B series 7700B series	901649-2 wire 900759-5 wire	none	none	910910
7600B series & 7600A series 7700 series & 7700A series	901649-2 wire 900759-5 wire	900760	none	910910
8600B series 8800B series	901649-2 wire 900759-5 wire	900937	none	910910
7600 series & 7900 series Equipped with "Blend Air"	901649 - 2 wire 900759-5 wire	911146	none	910910
7900 series & 4000 series DGAT - BDA series ex: DGRT - AUA series 7966-856	901998 blower+ 9011994-2 wire or 9011995-5 wire	none	none	none
DGAT - BDC series* DGRT - AUB series*	901998 blower‡ 901998 blower‡	902522 902522	none none	none none

*\*Furnace is factory wired for 4-wire AC, no control kit needed. ‡Blower change-out is required for 3 Ton A/C or larger*

7970C856	901998	Blower up to 3 1/2 ton	901995	5 Wire
	901999	Blower up to 4 ton	901994	2 Wire
DGAT - 056	BDE	3 ton AC ready - no blower needed		
DGAT - 070	BDE	3 ton AC ready - no blower needed		
DGAT - 075	BDE	3 ton AC ready - no blower needed		
DGAT - 090	BDE	3 ton AC ready - no blower needed		